
INSTALLATION INSTRUCTIONS

- 1. ENSURE APERTURE IS CLEAN AND FREE OF DUST AND DEBRIS
- 2. CUT THE RYANBATT 502 TO THE REQUIRED SIZE AND SHAPE TO FIT TIGHTLY WITHIN THE APERTURE
- 3. CUT THE RYANBATT 502 TO FIT TIGHTLY AROUND THE PVC PIPE
- 4. CUT THE RYANBATT ACROSS THE SHORTEST DIMENSION INCORPORATING THE MIDPOINT OF THE PENETRATION TO ENABLE THE BOARD TO BE FITTED INTO THE APERTURE.
- 5. APPLY RYANFIRE BRUSH GRADE MASTIC TO ALL THE EXPOSED & CUT EDGES OF THE RYANBATT.
- 6. INSERT THE RYANBATT INTO THE OPENING.
- 7. APPLY A BEAD OF MASTIC TO THE JOINT BETWEEN THE RYANBATT AND THE PVC PIPE.
- 8. APPLY A 5MM BEAD OF RYANFIRE MASTIC TO THE PERIMETER OF THE RYANBATT AND TO ANY JOINTS AND GAPS.
- 9. SELECT THE CORRECT SIZE RYANFIRE SL COLLAR TO FIT AROUND THE PIPE.
- 10. SECURE THE SL COLLAR AROUND THE PIPE AND SLIDE IT UP UNTIL IT IS FLUSH WITH THE RYANBATT. FIX THE SL COLLAR INTO PLACE USING 75MM SPIRAL SCREWS.
- 11. REPAIR ANY DAMAGE THAT MAY HAVE OCCURRED TO THE COATING DURING INSTALLATION USING RYANFIRE MASTIC.
- 12. REPEAT THIS PROCESS TO THE OPPOSITE SIDE OF THE WALL.



May 2022

Rev

3.0