INSTALLATION INSTRUCTIONS 1. THE WALLS HOULD BE CONSTRUCTED AS PER THE MANAPACTURERS SPECIFICATIONS. 2. ENSURE THE AREA WHERE THE MASTIC CO THE JOINT BETWEEN THE PAPELIE SCIENA NARP FREE TO DIST AND DEBRIS. 3. APPLY RYANFIRE MASTIC TO THE JOINT BETWEEN THE PLASTERBOARD SHEETS, TO THE JOINT BETWEEN THE MASTIC PLASTERBOARD SHEETS, TO THE JOINT BETWEEN	performance of a limited to size of passing through, Ryanfire technica performance info RYANFIRE Technifo@ryanfir Drawing Title Ryanfire I 90mm pla Scale NTS	Full width of the boar 60 minutes 1: 45 minutes 1: 45 minutes	I / linear seal d wall d tapers ire but not trations are ase refer to nd specific fire 362 nt seal
following the latest published drawings, test evidence and instructions. Whilst <b>Ryanfire Products Ltd</b> will endeavour to keep its publications up to date, the accuracy of the information contained within this drawing may be affected by pertinent changes in the law or regulatory requirement alterations or amendments to the specification of <b>the manufactured</b> products. Terms and conditions of sale apply.	Drawing Number	46.5	Rev 1.0