## INSTALLATION INSTRUCTIONS

- 1. ENSURE THE APERTURE IS CLEAN. FREE OF DUST AND DEBRIS.
- 2. CUT THE RYANBATT 502 TO THE CORRECT SIZE TO FILL THE TRAPEZOIDAL PROFILE. ENSURE THE RYANBATT EXTENDS 100MM EITHER SIDE OF THE CORED APERTURE.
- 3. APPLY RYANFIRE BRUSH GRADE MASTIC TO WHERE THE RYANBATT WILL MATE WITH THE SURFACE OF THE FLOOR, AND TO ALL CUT AND EXPOSED EDGES OF THE RYANBATT.
- 4. SECURE RYANBATT 502 INTO POSITION USING 75MM CONCRETE ANCHORS AND PENNY WASHERS 50MM FROM THE EDGE AND AT CENTRES NOT EXCEEDING 200MM.
- 5. SEAL ANY GAPS AND JOINTS WITH RYANFIRE BRUSH GRADE MASIC.
- 6. APPLY RYANFIRE MASTIC TO THE JUNCTION BETWEEN THE PVC PIPE AND THE FLOOR / RYANBATT ON BOTH SIDES OF THE FLOOR.
- 7. FIT THE SL-X COLLAR AROUND THE PVC PIPE.
- 8. SLIDE THE COLLAR ALONG THE PIPE UNTIL IT IS HARD UP AGAINST THE UNDERSIDE OF THE FLOOR / RYANBATT 502.
- 9. FIX THE RYANFIRE SL COLLAR INTO POSITION USING A COMBINATION OF:
  - A. MINIMUM 32MM CONCRETE ANCHORS AND PENNY WASHERS FOR THE FLOOR PROFILE PFAKS.
  - B. MINIMUM 75MM CONCRETE ANCHORS AND PENNY WASHERS FOR THE FLOOR PROFILE TROUGHS
- 10. FIXINGS MUST HAVE A MINIMUM 25MM EMBEDMENT INTO THE CONCRETE.
- 11. APPLY A NOMINAL 5MM BEAD OF RYANFIRE MASTIC TO THE JUNCTION BETWEEN THE COLLAR AND THE FLOOR / RYANBATT.

